

SAMSUNG NASA SYSTEMS COMPATIBILITY LIST



Document Version : 3.0

Last Revision : 17.09.2024

Product Code : CR-CG-SMG-KNX-01

1. PRESENTATION

In this document, compatible Samsung Nasa AC models with Core Samsung NASA Gateway (CR-CG- SMG-KNX-01) are specified.



Any AC indoor unit not specified in the list may not be compatible with Core AC Gateway. Therefore compatibility list must be checked before installation.



Any remote controller not specified in the list may not be compatible with Core AC Gateway. Therefore compatibility list must be checked before installation.



We highly recommend to pay attention to the possible updates of this document in case of any misprint, typing error and equivalent problems.



Core Smart Home undertakes maximum effort to avoid any error in the content of this document but cannot be responsible for the consequences that could arise because of any mistake in the document.

2. COMPATIBLE AC INDOOR UNITS

CORE SAMSUNG NASA KNX GATEWAY COMPATIBLE MODELS (INDOOR UNIT)	
SEMI INDUSTRIAL	AC_RNLDKG AC_RNMDKG AC_MNMDKH AC_JNHPKH AC_KNHPKH AC_RN4PKG AC_MN4PKH AC_NN4DKH AC_RN4DKG AC_RNNDKG AC_RN1DKG AC_RNJDKG AC_RNCDKG AC_RNCDKG AC_RNTDKG AC_RNADKG
FREE JOINT MULTI	AJ_TNMDEG AJ_TNLDEG AJ_TNLPEG AJ_TNNDKG AJ_TN1DKG AJ_TNJDKG

	AM_HNMPKH
	AM_KNLDEH
	AM_FNLDEH
	AM_FNMDEH
	AM_KNMDEH
	AM_FNHDEH
	AM_FNFDEH
	AM_HNHPKH
	AM_JNHFKH
	AM_KNLDEH
	AM_MNEPEH
	AM_KN4DEH
	AM_FN2DEH
	AM_NN4DEH
	AM_FN4DEH
	AM_HNNDEH
	AM_NNNDEH
DVM	AM_NN1DEH
	AM_NN1DKH
	AM_HN1DEH
	AM_NN1PEH
	AM_FNCDEH
	AM_FNCDEH
	AM_JNC DKH
	AM_FNJDEH
	AM_KNJDEH
	AM_MNFDEH
	AM_RNPDKH
	AM_TNADKH
	AM_TNVDKH
	AM_JNVDKH
	AM_KNTDEH
	AM_JNADKH
	AM_KNQDEH
	AM_FNKDEH

3. INSTALLATION SCENARIOS

INSTALLATION WITH SAMSUNG NASA WIRED REMOTE CONTROLLERS

Connect Core AC Gateway parallel with Samsung NASA wired remote controllers or directly to the F3-F4 connectors of Samsung NASA indoor unit. In this method, only one controller can be master. Core AC Gateway should be programmed as master, while Samsung NASA wired remote controller programmed as slave or Core AC Gateway should be programmed as slave, while Samsung NASA wired remote controller programmed as master.

INSTALLATION WITHOUT SAMSUNG NASA WIRED REMOTE CONTROLLERS

Connect Core AC Gateway directly to the F3,F4 connectors of the Samsung NASA indoor unit. In this scenario, Core AC Gateway should be programmed as Master.